

MODIF FREQUENCE CRT 279UV

Allumer l'appareil, puis tout de suite appuyer sur le bouton de sélection de droite : un menu password apparait : entrer le code 1001201 avec les touches du micro

Puis entrer les fréquences VHF : 1361741 ; qui correspondent à la bande de fréquence 136 Mhz a 174 Mhz

Puis Entrer les fréquences UHF : 4004701 qui correspondent à la bande de fréquence 400 Mhz a 470 Mhz

Pour revenir à l' origine faite la procédure inverse

144 Mhz – 146 Mhz et 430 Mhz – 440 Mhz

EXPAND FREQUENCIES CRT 279UV

Turn on the CRT 279 UV and immediately after press and hold the right selection button

A password menu appears: enter the code 1001201 with the keys of the microphone

Input the VHF frequencies like this: 1361741 which corresponds to the chosen frequency band from 136 Mhz to 174 Mhz

Input the UHF frequencies like this: 4004701 which corresponds to the chosen frequency band from 400 Mhz to 470 Mhz

To return to the origin made the reverse procedure

144 Mhz - 146 Mhz and 430 Mhz - 440 Mhz